

## Objective

Protocol 1 determines the optimal dilution and EV concentration for EV-containing samples, including culture media and fractionated plasma or other biofluids. The Protocol includes the necessary controls (buffer-only, reagent-only) and a sample serial dilution to determine assay dynamic range and lack of coincidence (swarm). This experiment also defines the optimal sample dilution (the dilution that produces ~50,000 Vesicle counts) for use in surface cargo measurement or other assays.

## Materials

- vFRed™ Membrane Stain (100x)
- vFC™ Staining Buffer, 2 mL
- Sample (concentrated culture media or fractionated biofluid)
- v-bottom plate

## To be provided by User

- Gloves
- Pipettes (5 uL – 300 uL)
- Pipette tips

## Procedure

*This Procedure is designed for two samples, for example conditioned media plus an untreated media control.*

### Prepare Working Solutions


- Prepare 10x vFRed™ stain solution (5 uL per well + 1 well)
  - For 2 samples plus controls (14 wells), 80 uL: add 8 uL vFRed™ (100x) to 72 uL vFC™ Staining Buffer.

### Prepare Samples

- Prepare serial dilutions of samples (Table 1.1 and Plate Map):
  - Pipet vFC™ Staining Buffer into Rows A-H.
  - Pipet 9 uL of EV samples into Row G and mix by pipetting up and down.
  - Serially dilute EV samples up Rows F to B by transferring 45 uL from Row G to F, then 45 uL from Row F to E, and so on to row B. Discard 45 uL at row B.
- Add 5 uL 10x vFRed™ to all samples except Row H. Mix well, incubate 1 hour at RT.

	Row	Buffer	Sample	vFRed	Total
Buffer +vFRed™	A	45	0	5	50
Sample 1:320	B	45	45	5	50
Sample 1:160	C	45	45	5	50
Sample 1:80	D	45	45	5	50
Sample 1:40	E	45	45	5	50
Sample 1:20	F	45	45	5	50
Sample 1:10	G	81	9	5	50
Buffer-only	H	50	0	0	50

Discard 45 uL



## Dilute and Read

4. Dilute the staining reaction according to Table 1.2.
  - a. Add the indicated amount of Staining Buffer to Columns 3-6
  - b. Transfer the indicated amount of stained sample from Columns 1-2 to Columns 3-4, and mix well.
  - c. Transfer the indicated amount of the Dilution 1 samples in Columns 3-4 to Columns 5-6, and mix well.
  - d. Run the wells in Columns 5-6 at the indicated sample flow rate for 120 seconds each.

Table 1.2 Post-stain dilution and run			
Wells	CytoFlex, Aurora	CellStream	ImageStream
Staining	50 uL	50 uL	50 uL
Dilution 1	8 µL → 245 uL	8 µL → 105 uL	5 ul → 145 uL
<u>Dilution 2</u>	8 µL → 245 uL	8 µL → 105 uL	None
<b>Post-stain Dilution</b>	1000	200	30
<b>Run</b>	High 60 uL/min	Slow 3.7 uL/min	Fixed

## Data Analysis

1. Open the vFC Analysis Layout with FCS Express Reader.
 

**Note: The vFC Analysis Layout has additional notes and tips to guide the data analysis.**
2. Load the appropriate calibration results into the Surface Area parameter via Tools>Transforms>Parameter Math (See Protocol 0).
3. From the Data List, click the Add File (+) and select the Protocol 1 data files.
4. Order the files by time (by clicking on the \$ETIM column in the Data List).
5. Select the file from Well A1, a **Buffer +vFRed** data file, and Change Data On All Plots. On the Gating Tab, inspect the Gating Plots. Adjust Time Gate, Pulse Gate, and Vesicle Gate as needed to minimize low- and high-scatter backgrounds.
6. Select a **Sample** data file and Change Data On All Plots. Inspect the Gating Plots. Adjust Gates as needed to select vFRed-positive events.
7. Export sample information and statistics using using Batch Processing.
8. On the **Dilutions Tab**, select a set of serial dilution data (eg Wells B11-BG11) and load them into the overlay plots indicated. When data files are properly annotated, the plot titles and legend will be populated with the sample name and dilution, and the Vesicle Gate counts and Median Diameter will be plotted as a function of the dilution factor.
9. Copy the Batch Output data into the Data field of the vFC Protocol 1 Analysis template.

## Example Data

## Notes

### CytoFlex-specific Instructions:


#### Before loading data files

#### Configure FCS Express Options to recognize CytoFlex data file parameters by name:

File>Options>Data Loading> Instrument Specific Settings> CytoFLEX>General Options>

Keyword to Use as Parameter Name: **Stain**  
 Keyword for Parameter Matching: **Stain**

Click: **OK**



Developed, Manufactured, and Distributed By

**Cellarcus Biosciences, Inc.**

Telephone: +1 (858) 239-2100

Customer Care: [cellarcus@cellarcus.com](mailto:cellarcus@cellarcus.com)

Technical Support: [technical@cellarcus.com](mailto:technical@cellarcus.com)